

This diagram is for plumbing a balanced draw from two tanks. In this configuration, the tanks will drain evenly. It is important to have the hoses from the tanks to the T be the same length.

Coolant In

Vent

Coolant Out

**Plumb Together
With 1/2" Hose**

Return

**To The "In"
Port On The Filter**

